

## Fascia Corner Install

1. Install fascia 1 ½" in from corner of deck. Be sure to install fascia to manufacturer specs.
2. Place Fascia Corner on the corner of the deck framing and use composite deck screws to attach. Four screws are needed per Fascia Corner placed 1" from top and bottom edges and 1 ½" from side edges. **Deck boards must have 1" overhang.**

## Install Notes

- When installing fascia corners do not over tighten.
- Fascia must be flat against rim joist. If fascia is cupped this may result in cracking, breakage, or failure of product. Pre-drilling holes (according to manufacturer specs) is suggested for ease of installation. Only use approved deck screws. **DO NOT USE FASCIA SCREWS.**

