



HG THERMAFORM SOLUTIONS, INC  
SINCE 2023

## Fascia Keystone Install

1. Install fascia to manufacturer specifications, leaving 4 ¾" between splices in the fascia for proper manufacturer gapping.
2. Place Fascia Keystone between the 4 ¾" gap in the fascia and use 4 composite deck screws to attach to the framing. **Deck boards must have a minimum 1" overhang.**

### Install Notes

- When installing Fascia Keystone DO NOT over-tighten screws
- Fascia must be flat against the rim joist. If fascia is cupped this may result in cracking, breakage, or failure of the product.
- Pre-drilling holes (according to manufacturer specifications) are suggested

